

## **PURPOSE BUILT CABS**



## PURPOSE BUILT CABS

Designed with extensive input from Loggers, Brightwater Forestry FOPS, OPS & ROPS Cabs provide optimum protection, visibility and durability for the operator.


Manufactured to fit most machine makes and models, Brightwater Forestry Cabs are constructed using reinforced grade 350 steel and super-strong polycarbonate glass to ensure maximum protection whilst maintaining excellent visibility and reducing exterior noise for the operator.

The top hatch and side door are accessible from the outside and the two side opening windows give added escape options in an emergency. All Brightwater Cabs come standard with heavy duty hinges and a hydraulic door with stand alone powerpack. The design of the cab also reduces external noise increasing operator comfort levels.

# PURPOSE BUILT CABS



# **KEY FEATURES**



#### Nelson

Physical Address: 7 Spencer Place Brightwater, Nelson, 7022 Postal Address: PO Box 43, Brightwater, Nelson 7051

Phone: +64 (3) 543 5300

Fax: +64 (3) 543 5301

Email: inquiries@brightwater.co.nz

Website: www.brightwater.co.nz

### Greymouth

Physical Address: 69 Jacks Road, Greymouth, 7805
Postal Address: PO Box 138, Greymouth, 7840
Phone: +64 (3) 768 5374
Fax: +64 (3) 768 5379
Email: inquiries@brightwater.co.nz
Website: www.brightwater.co.nz

### Auckland

Physical Address: 6 George Bourke Drive, Auckland, 1060 Postal Address: PO Box 132-072, Sylvia Park, Auckland, 1644

 Phone:
 +64 (9) 480 8409

 Fax:
 +64 (9) 480 8109

 Email:
 inquiries@brightwater.co.nz

 Website:
 www.brightwater.co.nz